

Contribution to the optimization of clarification of cashew apple juices by tangential microfiltration: identification of the foulant fractions and implementation of filterability tests

Doudjo SORO, Michèle DELALONDE, Christelle WISNIEWSKI, Manuel DORNIER

UMR Qualisud, Montpellier, France



International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

CONTEXT

- ❑ To valorize cashew apple in juice
 - ✓ Côte d'Ivoire product 3 million t/year
 - ✓ Almost all production is not utilized
 - ✓ cashew apple is rich in vitamin C, polyphenols sugars
- ❑ To use Membrane process to clarify cashew apple juice
 - ✓ Cashew apple juice is astringent

International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

OBJECTIVES

- ❑ To determine the main foulant fractions of cashew apple juices
- ❑ To implement tests of filterability
Prediction of the filtration performance

International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

EXPERIMENTAL APPROACH

- ❑ Juice filterability measurements
 - ✓ Specific resistance to filtration (SRF)
 - ✓ Capillary Suction Time (CST)
- ❑ Membrane permeability measurements
 - ✓ Stabilized permeate flux for defined VRF (J_p)

Lab-scale experiments

Pilot-scale experiments


Cashew apple juices

Different fractions of cashew apple juices

International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

EXPERIMENTAL APPROACH


Raw cashew apple juices



International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

EXPERIMENTAL APPROACH

Specific resistance to filtration (SRF)



Cake filtration 's Law



Stirred Ultrafiltration Cells
AMICON - Model 8010

Cellulose nitrate membrane 0,2 μm - 2 bar

International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

EXPERIMENTAL APPROACH

Capillary Suction Time (CST)

The CST is derived from the time taken to draw a known volume of filtrate from a suspension by the capillary suction pressure generated from standard CST filter paper.

Capillary Suction Time has been established as a reliable method for assessing **sewage sludge** filterability.
However the CST technique can be used on **any colloidal aqueous suspension**.



Triton Type 319 Multi-purpose CST

International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

EXPERIMENTAL APPROACH

Clarification experiments – Pilot unit and operating conditions

For clarification, a pilot of micro-filtration was used. It contains four modules connected in series. Each module contained a ceramic membrane of 0.2 μm of pore size.

- Operating conditions:
- ✓ Crossflow velocity: 6 m.s⁻¹;
 - ✓ Temperature: 35±2°C;
 - ✓ Average transmembrane pressure: 2bar



Pilot Unit


International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

RESULTS – Juice characteristics

	JM	JB	JM
pH	4.05 (0.29)*	3.90 (0,21)*	4.06 (0.15)*
Titrateable acidity (g malic acid.kg TSS ⁻¹)	2.94 (0.08)*	2.61 (0,09)*	2.66 (0.05)*
Total soluble solids (TSS) (g.kg ⁻¹)	52 (2)*	56 (2)*	56 (2)*
Total Solids Content (TSC) (g.kg ⁻¹)	65 (2)	60 (2)	60 (2)
SIS (g.kg ⁻¹)	7.78 (0.46)	3.32 (0.19)*	0**
Tannins (g.kg TSS ⁻¹)	23.10 (0,13)**	2.1 (0,01)*	0
Alcohols-insoluble solids (AIS) (g.kg TSS ⁻¹)	3.81 (0.15)**	0.25 (0.02)*	0
Viscosity (mPa.s ⁻¹)	1.24 (0.07)	1.05 (0.05)	1.13 (0.04)
Turbidity (UNT)	8 033 (907)**	233 (15)*	6 (<1)*
Vitamin C (g.kg TSS ⁻¹)	15.0 (0.5)	14.2 (0.1)	14.1 (0.7)
Total nitrogen (g.kg.TSS ⁻¹)	4.04	2.09	1.89


International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

RESULTS – SRF




International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

RESULTS – CST



International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

RESULTS – Permeate flux



International Conference on Membrane Science & Technology
MST2012: Sustainable Energy and Environment

RESULTS – DISCUSSION

- ❑ JB (Raw juice) : contains more tannins, total nitrogène, AIS, SIS than JD (Decanted juice) one.
- ❑ JM (Clarify juice): not contains tanins, AIS and SIS. Total nitrogène is reduced
- ❑ Jp of JM ($116 \text{ L.h}^{-1}.\text{m}^{-2}$), is very raise than JB ($39 \text{ L.h}^{-1}.\text{m}^{-2}$) and JD ($40 \text{ L.h}^{-1}.\text{m}^{-2}$).

RESULTS – DISCUSSION

	JB	JD	JM
Jp ($\text{L.h}^{-1}.\text{m}^{-2}$) ($3 < \text{VRR} < 8$; $\text{TMP} = 2 \text{ bar}$)	39	40	116
SRF ($\text{Kg}.\text{m}^{-1}$)	$3.15 \cdot 10^{12}$	$106 \cdot 10^{12}$	$5.51 \cdot 10^{12}$
CST (s)	9.8 (0.9) ^a	7.9 (0.7) ^b	6.6 (0.9) ^b

- ❑ JD has a different behavior of other juice during filtration with cell amicon. Its SRF is very high but its permeate flux is the same than JB.

RESULTS – DISCUSSION

- ❑ The JB having the lowest SRF, should in principle have the permeate flux is higher. But this is not the case
- ❑ This means that we can not use the filterability tests on Amicon cell to predict the permeate flux of juice

RESULTS – DISCUSSION

- ❑ The values of the Capillary Suction Time (CST) of JD and JM are statistically identical. However, the permeate flux are very different;
- ❑ We can not use the filterability tests on CST to predict the permeate flux of juices

CONCLUSION

- ❑ This study shows that:
 - ✓ simples filterability tests can not be used to predict permeate flux during microfiltration;
 - ✓ The colloidal fraction is responsible for membrane fouling in crossflow microfiltration;
 - ✓ Crossflow microfiltration removes the astringency of cashew apple juice.